

ADDITIONAL INFORMATION

Product Name : 5D Levitating Portable Bluetooth Speaker

Color : Grey

This is one UFO sighting that sounds as cool as it looks! Our new generation levitating speaker hovers over its magnetic base and spins so you get 360 degrees of stereo surround sound. The long-life lithium battery lasts for up to 8 hours so it's perfect for outdoor patio parties or just hanging out with friends. Plus, it works with virtually any Bluetooth device to play your favorite MP3 and WMA formatted songs.



Bluetooth 4.0 Technology

10 Meters Bluetooth Range
Easy to Contact with Your Devices



Full Compatibility


It is compatible with most devices that have Bluetooth



Hands-Free Phone Call

Pop Up design Hands-free for Everywhere: Built-in Microphone to make the phone call clearly






360° Stereo Surround

Enjoy full-circle crisp and clear music in wide spaces on every corner




Specification

Bluetooth Version: 4.0
 Interface Type: USB
 Loudspeaker Unit: 2.0in
 Amplifier Power: 5W
 Battery Capacity: 1500mAh
 Connection Range: 10 meters
 Audio Input: mono
 Frequency range: 160Hz-20kHz
 USB Output Voltage of Base: 5V
 Play Format: MP3, WMA
 SNR: ≥75dB
 Operation Mode: button
 Playback Time: 8h
 Working Temperature: 14~140°
 Appearance Material: ABS + PC



Structure



1. Base Supports

2. Breathing LED Indicator

3. Reset

4. Micro USB Interface

5. Power Input Interface (Base)

6. USB Interface

7. Power Switch On/Off
Phone Call Answer/Hang-off

8. Microphone

Startup

The speaker part (UFO speaker) of this product has built-in Lithium battery, please recharge the UFO speaker before first time use.

Power On/Off

Base Power On

Plug-in the 12V/1.25A power adaptor to the base. The LED indicators at the edge of the base will be activated when power is on.

Base Power Off

Pull-out the 12V/1.25A power adaptor from the base. The LED indicators at the edge of the base will be deactivated when power is off.

Speaker Power On

Press and hold the power button on the UFO speaker for a few seconds to power-on. When power-on, the speaker will emit power-on sound and the breathing LED indicators surrounding the edge of the speaker will be activated.

Speaker Power On

Under power-on status, press and hold the power button of the speaker for a few seconds to power-off. When power-off, the speaker will emit power-off sound and the breathing LED indicators surrounding the edge of the speaker will be deactivated.

Setting UFO Shape Speaker to Levitating Status

Place the magnetic base onto a flat & stable surface and power-on. Hold the UFO speaker with both hands horizontally at approx. 8cm right above from the base. Slowly lower the speaker till approx. 3cm from the base. During the lowering and adjusting process, the four LED indicator on the base will be flashing to indicate whether the position of the speaker is properly set. When the speaker is moved to right position, all LED indicators on the base will be continuously and consistently on.

Gallery







FOR MORE INFORMATION TO INCLUDE:

1. OTHER DOCUMENTATION

Please email us at: bizdev@freeworldimports.com